



Installation and Care of SP-3V Vertical Grab Bar

Warning: This product is ligature-resistant only when properly installed. A loosened fixture can easily be tied to. Any product which can be removed can be used as a weapon!

Installation:

1. Secure to the wall using 1/4-20 fasteners¹ through the mounting holes in the flanges. Use washers to prevent the fastener heads from damaging the finish. (*Fasteners and washers are not included.*) Grab bars are supports, and therefore require adequate anchoring into a structurally sound wall.
2. Verify that the grab bar cannot be loosened or removed.
3. If any gaps exist between the SP-3V and the wall, fill them with a security sealant (such as Pecora Dynapoxy EP-1200).

Care and Maintenance: Care should be taken when cleaning to protect the finish. Clean with mild detergent and a non-abrasive cloth. Aggressive cleaning techniques may remove the finish. Do not use abrasive cleaners or chemical solvents

¹ Security fasteners are strongly recommended. The selection of a particular size and type of security fastener should be made in conjunction with a facility manager, because it depends upon factors such as construction materials and institutional standards.



Odd Ball Industries

Ligature-Resistant Safety Products

